
# ASSEMBLY INSTRUCTIONS ITEM No.:HRN.KD.D1








Turn clockwise to lock cam with bolt.




The arrow direction-front



Screw cam bolts all the way in.

î



1.76



# PARTS LIST

ITEM	QTY	
Α	Top panel	1
G	Bottom panel	1
D	Back panel	2
X	Left side panel	. 1
Z	Right side panel	1
F	Shelf Panel	6
01	Panel	2
02	Panel	1
Y	Partition	1



# **PARTS LIST**

ITEM	DESCRIPTION	QTY.	ITEM	DESCRIPTION	QTY.
(c1)	6*35 Cam Bolt	28	61	6*30 Fix Bolt	4
(d)	8*30 Dowel pin	12	(c3)	Cover	4
<u>©</u> 2	(1/8") Cam Cover	-28	(s5)	Feet	4
			a	Wrench	1







6 6\*35 Cam Bolt-32

6 8\*30 Dowel Pin-20

② (¾ Cam Cover-32



S Alignment Pin-6





a Wrench-1



6 6\*30 Fix Bolt-4




COVE

Pre-installed parts





# STEP 1




#### Preparing panel A.G.X.Z.F.Y and O1.

- 1. Insert cams bolts (1) into panels A.G.X.Z and Y as illustrated above.
- 2. Insert dowel pins (1) to panels X.Z.O1.F and Y as illustrated above.



## STEP 2




#### Panel Z.Y and F assembly.

1.Insert cam bolts ⊚ on panel Y and Z into cams on panels F and tighten in a clockwise direction as illustrated above.

## STEP 3

10 16




#### Panel X.O1 and O2 assembly.

1.Insert cam bolts 

on panel X and Z into cams on panels O1 and O2 and tighten in a clockwise direction as illustrated above.






#### Panel A assembly.

1.Insert cam bolts 
on panel A into cams on panels Y.O1.X and Z and tighten in a clockwise direction as illustrated above.

## STEP 5


2 90



Panel D and Plastic strip assembly.

1.Insert panel D into panel X.Z and A illustrated above.






#### Panel G assembly.

- 1.Insert cam bolts @ on panel G into cams on panels Y.O1.X and Z and tighten in a clockwise direction as illustrated above.
- 2. Insert feet s5 into panel G.

## STEP 7




### Fix Bolt assembly.

1. Connecting Cabinet A and B is using Wrench a to insert Fix Bolt b3 as illustrated above.



You have now successfully completed the assembly on item:

# ITEM No.:HRN.KD.D1



-0.75

