

Accessories not included

Kensington Sewing Cabinet

Congratulations on the purchase of your new Kensington Sewing Cabinet. Every effort has been taken to ensure your complete satisfaction with this custom designed product. For your convenience the Kensington Sewing Cabinet is supplied in three ready to assemble packs.

Helpful Assembly Hints

Read the instructions carefully before starting. Check to see that all the parts are included. Work in a spacious area preferably on a carpet or soft surface. You will need a phillips head and flat head screw driver for the assembly. A cordless drill is preferable. Make sure you tighten all the screws securely and tap dowels all the way in.

Warranty Information

Horn Australia Pty Ltd warrants this Kensington Sewing Cabinet to be free from faulty parts or workmanship for a period of 12 months from the date of purchase. Under the terms of this warranty the repair and replacement of any parts shall be at the discretion of the company or their designated representatives. The warranty does not cover damaged caused by abuse, alteration, accident or neglect. The warranty does not cover damage caused as a result of moving the cabinet when loaded. Should service become necessary during the warranty period please contact your nearest Horn retailer. Product transportation is at the owner's responsibility.
























Cabinet Care




Your Horn Kensington Sewing Cabinet normally requires a minimum amount of maintenance, however the following points are worth noting:



















Cleaning - To remove marks and enhance the surface, wipe over with a general purpose cleaner.

Caution - Do not use ammonia based cleaning agents. Do not use harsh chemicals or abrasive cleaners. The surface can be wiped with a damp cloth but should be dried quickly.

KENSINGTON ASSEMBLY INSTRUCTIONS

COMPONENTS	DESCRIPTION	QTY
	Cam Bolt 24mm	12
	Cam Ø15mm	12
	Screw Ø5 x 57mm	6
	Cover Cap <small>(For Screw 5x50) (Teak, Beech, SS)</small>	4
	Dowel Ø8 x 30mm	32
A 	Screw Ø3.4x15mm C/S	94
D 	Screw Ø3.5x18mm C/S	10
E 	Screw Ø3 x 25mm C/S	10
F 	Screw Ø6 x 10mm C/S	4
	Castor Washer	5
	Castor Ø50	5
	Castor Ø50 Lockable	3
	Castor Bracket	3
	Castor Spanner	1
	Cam Ø15x10mm	2
	Screw Ø4 x 32mm	4
	Cam Bolt 24mm	2
	Flap Hinge	3
	Butt Hinge	2
	Flush Hinge (52mm)	6
	Drawer Runner 350	1 Set
	Bow Handle + Screws	2
	Glue Bottle	2


	Lock Striker	1
	Equalizer	2
	Lock & Key	1

COMPONENTS	DESCRIPTION	QTY
	Insert Holder	1
	Lifter Rail (Right)	1
	Lifter Rail (Left)	1
	Lifter (692mm)	1
	Button (Gate Leg)	1
	Door Plate	2
	Swivel Tray Bracket	2
	Door Shelf (Left)	1
	Door Shelf (Right)	1
	Large Bucket	1
	Swivel Tray (Ass.)	2
	Cotton Reel Insert	2
	Drawer Tray	1
	Plastic Handle	1
	Stay Arm (Long)	1
	Stay Arm Bracket	1
	Escutcheon	1
	Ramp	3
	Basket Insert	1
	Pin Cushion Foam	2


KENSINGTON ASSEMBLY INSTRUCTIONS

KENSINGTON PANELS AND THEIR DESCRIPTIONS


Note: Hole positions helps with panel orientation.




BACK



BACK FLAP




SMALL DOOR




Before assembling place 2 to 3 drops of glue in each dowel hole.


Do Not place glue in Cam or Cam Bolt holes.




LARGE DOOR




DIVISION




L/H END




R/H END




GATE LEG




LIFTER BOARD




R/H Side




Back



L/H Side



BOTTOM




TOP / FLAPS




SHELF



DRAWER FRONT




DRAWER BASE




DRAWER SIDE

1. Top/Flap Pre-Assembly




Cam Bolt (x5)



Stay Arm



Ramp (x2)




Screw E Ø3 x 25mm C/S



Screw D Ø3.5x18mm C/S

Assembly Steps


1. Screw the Cam Bolts into the Top panels as shown.
2. Fix the Ramps to the Top using Screw D Ø3.5 x 18mm
3. Fix the Stay Arm to the Top using Screw E Ø3 x 25mm




2. Bottom Pre-Assembly



Cam Bolt (x5)



Bottom Panel




Insert Holder



Screw A Ø3.4 x 15mm C/S

Assembly Steps

1. Screw Cam Bolts into Bottom as shown
2. Fix Insert Holder to Bottom using Screw A Ø3.4x15mm C/S




3. R/H End Pre-Assembly



Dowel (x4)




Cam (x4)



R/H Lifter Rail



Screw A Ø3.4x15mm C/S




Right Hand End

Assembly Steps

1. Insert Dowels using 2 to 3 drops of Glue into each end.
2. Place Cams into holes shown
3. Screw R/H Lifter Rail onto End using Screw A Ø3.4x15mm C/S



Note:

Lifter Rail will be level with the panel edge.



KENSINGTON ASSEMBLY INSTRUCTIONS




4. Division Pre-Assembly



Assembly Steps

1. Press fit Cams into the Division. Ensure the arrow on the Cam points to the closest edge.
2. Place 2 to 3 drops of glue in the dowel holes in the Division then tap Dowels into place.
3. Screw on R/H Lifter Rail using Screw A Ø3.4x15mm C/S
4. Screw on Lock Striker using Screw A Ø3.4x15mm C/S


Note:
Rail will be level with panel edge



5. L/H End Pre-Assembly

Assembly Steps

1. Press fit Cams in the L/H End. Ensure the arrow on the Cams points to the nearest edge.
2. Place 2 to 3 drops of Glue in the dowel holes and insert the Dowels.



6a. Large Door Pre-Assembly




Flush Hinge (52mm)



Castor Bracket



Castor Ø50 Locking



Equalizer



Lock



Screw A Ø3.4x15mm C/S (x11)




Screw D Ø3.5 x 18mm C/S (x4)


Assembly Steps

1. Screw on Flush Hinge using Screw A Ø3.4x15mm C/S
2. Screw on Castor Bracket using Screw A Ø3.4x15mm C/S
3. Screw on Castor Ø50 Locking
4. Screw on Equalizer using Screw A Ø3.4x15mm C/S
5. Screw on Lock using Screw D Ø3.5x18mm C/S

STEP 1




STEP 3




STEP 2

Note:
Tap Castor Bracket into the hole in the edge of the Door before inserting screws.

STEP 5




STEP 4



KENSINGTON ASSEMBLY INSTRUCTIONS

6b. Large Door Pre-Assembly

STEP 1




Large Door Assembly



L/H Door Shelf



R/H Door Shelf





Swivel Tray Assembly (x2)




Screw Ø3.0 x 25mm (x4)

Assembly Steps

1. Screw on Left Hand and Right Hand Door Shelf using Screw Ø3.0 x 25mm.
2. Insert Swivel Tray assembly into the Left Hand and Right Hand Door Shelf




STEP 2



6c. Large Door Pre-Assembly


STEP 1



Large Door Assembly



Swivel Bracket (x2)



Large Bucket




Screw E Ø3 x 25mm C/S



Screw A Ø3.4x15mm C/S (x6)



Assembly Steps

1. Position Swivel Bracket
2. Screw on Swivel Bracket using Screw Ø3.0 x 25mm
3. Screw on Bucket using Screw A Ø3.4x15mm C/S



Screw E
Ø3x25mm C/S

Swivel
Bracket




Screw A
Ø3.4x15mm

Large Bucket


STEP 2

7. Small Door Pre-assembly




Assembly Steps

1. Screw on Stay Arm Bracket using Screw A Ø3.4 x 15mm
2. Screw on Flush Hinge using Screw A Ø3.4 x 15mm C/S
3. Screw on Castor Bracket using Screw A Ø3.4 x 15mm C/S
4. Screw on Castor (Lockable)
5. Screw on Equalizer using Screw A Ø3.4 x 15mm C/S
6. Screw on Door Plates using Screw A Ø3.4 x 15mm C/S




8. Back Flap Pre-assembly



Assembly Steps

1. Screw on Flap Hinge using Screw A Ø3.4 x 15mm C/S
2. Screw on Ramp using Screw D Ø3.5 x 18mm C/S




KENSINGTON ASSEMBLY INSTRUCTIONS

9. Gate Leg Pre-assembly



Gate Leg Button



Butt Hinge



Castor Bracket




Castor Ø50 Locking



Screw A Ø3.4x15mm C/S (x10)

Assembly Steps


1. Tap in Gate Leg Button
2. Screw on Hinge using Screw A Ø3.4 x 15mm C/S
3. Screw on Castor Bracket using Screw A Ø3.4 x 15mm C/S
4. Screw on Castor (Locking)




10. Lifter / Lifter Board Pre-assembly



Dowel (x 6)



Lifter Board



Lifter




Screw A Ø3.4x15mm C/S (x4)

Assembly Steps

1. Insert Dowels into Shelf using 2 to 3 drops of glue in each hole
2. Screw the Lifter to the Lifter Board using Screw A Ø3.4 x 15mm C/S


Note:

Lifter orientation on Lifter Board




KENSINGTON ASSEMBLY INSTRUCTIONS

11. Cabinet Assembly




Assembly Steps

1. Place 2 to 3 drops of Glue in the dowel holes in the Bottom. Insert R/H End onto Bottom Cam Bolts and tighten.
2. Position Back against the R/H End and fix using Screw Ø5.0 x 57mm & Cap




12. Cabinet Assembly



Assembly Steps



1. Place 2 to 3 drops of glue into dowel holes in the L/H End & Division insert Shelf.
2. Place 2 to 3 drops of glue in the dowel hole in the Bottom. Fit L/H End & Division onto Cam Bolts and secure by turning Cams a half-turn clockwise.
3. Fix Back to L/H End using Screw Ø5.0x57mm
4. Press Cover Cap into Screw




KENSINGTON ASSEMBLY INSTRUCTIONS

13a. Lifter / Cabinet Assembly

Step 1.



Cabinet Assembly



Lifter Board Assembly


Assembly Steps

1. Position Lifter guides over Rails and gently slide the Lifter into position.

Note:

Ensure all 4 plastic guides (2 on each side are positioned correctly.

13b. Lifter Cable Attachment




Assembly Steps

1. Loop Cable through Metal Tab on Lifter Rails & secure.
2. Push Lifter down and click into first stop position.


Note:

When the Lifter is clicked into this first stop position a small block of timber will disengage from the rear of the Lifter.


Discard block



14. Top & Cabinet Assembly



Assembly 14b



Top / Flaps


Assembly Steps

1. Place 2 to 3 drops of Glue into each Dowel hole.
2. Position the Top Panel Assembly over the Cabinet Assembly locating the Cam Bolts and Dowels.
3. Secure by rotating Cams a half turn clockwise.
4. Rotate Cabinet onto its Back and then Top carefully.



Note:

It will require 2 people to lift and rotate cabinet onto its top

STEP 1 A. Insert Cam bolt



B. Half Turn Clockwise To Tighten




STEP 3

STEP 2

15. Castor Attachment


Screw Ø5 x 57mm C/S (x2)

Cover Cap (x2)



Castor Ø50mm


Washer



Spanner

Assembly Steps

1. Secure the Bottom and Back together using Screw Ø5x57mm C/S
2. Press Cover Caps into the Screws
3. Place Castor Washers over Castor thread and screw into Bottom and secure using the Spanner.




Castor (x5)


Spanner

Castor Washer (x5)


Screw Ø5x57mm & Cover Caps



16. Back Flap Assembly



Cabinet Assembly




Back Flap Assembly




Screw A Ø3.4x15mm C/S (x9)

Assembly Steps

1. Fix the Back Flap to the Cabinet using Screw A Ø3.4x15mm C/S




Screw A
Ø3.4x15mm




17. Gate Leg Assembly


STEP 1.



Screw A
Ø3.4x15mm



Cabinet Assembly



Gate Leg Assembly




Screw A Ø3.4x15mm C/S (x6)

Assembly Steps


1. Fix Gate Leg to the back of Cabinet using Screw A Ø3.4x15mm C/S
2. Swing Gate Leg against Back
3. Roll Cabinet back over onto Castors

Note:

It will require 2 people to lift and rotate Cabinet safely.



18. Small & Large Door Assembly



Cabinet Assembly


Screw A Ø3.4 x 15mm C/S (x12)

Assembly Steps

1. Fit Small & Large Doors to Cabinet Ends using Screw A Ø3.4x15mm C/S

Note:

Fit Screws into pre-drilled holes and secure



19. Handle Assembly



Escutcheon




Bow Handle (x2)



Handle Screw (x4)

Assembly Steps

1. Press the Escutcheon into the Large Door.
2. Extend Stay Arm and position over the Stay Arm Bracket on the Small Door.
3. Press the end of the Arm firmly and clip into Bracket to secure.
4. Fit Handles in place and secure using Screws supplied



KENSINGTON ASSEMBLY INSTRUCTIONS


20. Opening Flaps Instruction

Assembly Steps


1. Open Doors and swing Flaps onto top of Doors
2. Lift Back Flap up and swing Gate Leg into position and lock in place.

Note:

Doors must be open and Castors locked in place before Flaps are opened and position on Doors




21. Drawer Runner Assembly



L/H & R/H
Drawer Runner 350mm



Screw F Ø6x10mm (x4)






Assembly Steps

1. Fit Left Hand and Right Hand Runners using Screw F Ø6x10mm


KENSINGTON ASSEMBLY INSTRUCTIONS

22. Drawer Assembly

-  Cam Ø15x10mm (x2)
-  Dowel Ø8x30mm (x6)
-  Cam Bolt 24mm (x2)

Assembly Steps

1. Place 2 to 3 drops of glue in each dowel hole in the Drawer Sides and insert Dowels.
2. Screw the Cam Bolts into the Drawer Front as shown.
3. Insert Cams into the Drawer Sides ensuring the arrow points to the front edge.



23. Drawer Assembly

-  Drawer Handle
-  Screw Ø4x32mm (x4)

Assembly Steps

1. Place 4 to 5 drops of glue around the Drawer handle and press fit into Drawer Front
2. Secure the L/H & R/H Drawer Sides to the Drawer Back using Screw Ø4x32mm
3. Insert Caps into the head of the screws.
4. Slide the Drawer Bottom into the Drawer Side groove.
5. Place 2 to 3 drop of glue in the dowel holes in the Drawer Front. Locate the Drawer Front and secure by turning the Cam a half turn clockwise.
6. Locate the Drawer on the runners and slide into Cabinet.

